








223634 BREAKDOWN

Item	Item Tag	Description	Quantity
1	HYV03958	ROD EYE	1
2	QUE00891	NUT	1
3	QUB00300	BUSHING	2



ARM HYD CONNECTION BREAKDOWN

Item	Item Tag	Description	Quantity
1	218843	HOSE	2
2	HYS00621	SUPPORT, Hose	6
3	ELA01300	SUPPORT, Hose	5
4	223671	HOSE	2
5	HYF02780	ADAPTOR, 45°	2
6	HYF06121	ADAPTOR, Tee	1
7	HYF10193	COUPLER, Test	1
8	HYF07300	ADAPTOR, 90°	2




ARM SLIDE ASSEMBLY BREAKDOWN

Item	Item Tag	Description	Quantity
1	186406	BRACKET, Roller	1
2	QUE02360	NUT	2
3	186426	WEAR STRIP, 1.5" Wide	3
4	186432	WEAR STRIP, 2.5" Wide	1
5	186402	PIN, Roller	2
6	QUR00915	ROLLER	2
7	QUV02720	CAPSCREW, Flat Head	40
8	QUB05025	CAPSCREW	1
9	QUR01695	WASHER	4
10	QUE01175	NUT	2
11	QUB02120	CAPSCREW	2
12	223647	WELDMENT, Arm Slide	1
13	QUR01912	WASHER	2
14	223641	PIN, Arm Pivot	1
15	QUG00200	FITTING, Grease	1
16	223654	PIN, Arm Lift Cylinder	1
17	223657	PIN, Arm Slide Cylinder	1
18	QUR01902	WASHER	4
19	QUR01300	WASHER, Lock	2
20	QUE01302	NUT	2
21	QUB04414	CAPSCREW	2
22	QUB06200	CAPSCREW	2
	223646	SLIDE, Assy. (Includes Items 1-12)	


ARM SLIDE WELDMENT BREAKDOWN

Item	Item Tag	Description	Quantity
1	223986	BRACKET, Slide Cylinder	1
2	223649	MOUNT PLATE, Lift Arm Pivot	1
3	186430	COLLAR, Lift Arm Pivot	1
4	223667	BRACKET, Arm Lift Cylinder	1
5	186483	BRACKET, Slide Roller	1
	223647	ARM SLIDE, Weldment	

Arm Slide Assembly Breakdown




Arm Slide Weldment Breakdown



VERSABINZ PARTS


CAN BREAKDOWN

Item	Item Tag	Description	Quantity
1	214896	CONTAINER, Residential	1
2	HYF11415	ADAPTOR, Plug	1
3	QUG02200	GROMMET	4
4	223519	GUARD, Upright	2
5	QUB03360	CAPSCREW	8
6	QUR01272	WASHER, Lock	33
7	QUR01902	WASHER	37
8	204534	DECAL	1
9	204537	DECAL	2
10	221960	DECAL	1
11	ETR00300	TAPE, Reflective	4
12	ELL02940	LIGHT, Work 4" (Clear)	2
13	QUG03000	GROMMET, 4" Light	2
14	223500	PLATE	2
15	223685	GASKET	2
16	QUB03401	CAPSCREW	14
17	224893	DECAL	1
18	223536	HOSE DEFLECTOR	1
19	Q-0404	CHAIN ATTACHMENT	2
20	223673	SHUTTER, R.H.	1
21	QUV01510	SCREW	1
22	QUR01704	WASHER	18
23	223672	SHUTTER, Rear	1
24	QUV01500	SCREW	17
25	223529	WIND SCREEN, L.H.	1
26	QUB03501	CAPSCREW	13
27	223530	WIND SCREEN, Front	1
28	QUE01302	NUT	2



EXTEND CYLINDER BREAKDOWN

Item	Item Tag	Description	Quantity
1	HYC00620	CYLINDER	1
2	HYF07400	ADAPTOR, 90°	2
3	223706	HOSE	1
4	223681	HOSE	1




VERSABINZ PARTS

GRABBER BODY BREAKDOWN

Item	Item Tag	Description	Quantity
1	186458	BUMPER PAD	1
2	203725	BRACKET SPACER	1
3	194328	BRACKET ASSY., Lower (Includes Items 4-6)	1
4	186493	BUSHING HOUSING	2
5	QUR00920	BUSHING	2
6	QUG00200	FITTING, Grease	2
7	183054	HUB	2
8	186537	BRACKET, Rubber Strap	2
9	QUE03975	NUT	2
10	QUP03220	PIN, Cotter	2
11	183055	BEARING	2
12	186509	GUARD	2
13	186521	KEY	2
14	QUE01814	NUT	2
15	QUV02450	CAPSCREW, Flat Head	6
16	QUR01700	WASHER	6
17	QUE01101	NUT	6
18	QUR01912	WASHER	10
19	QUE01500	NUT	4
20	QUE01495	NUT	2
21	QUB04601	CAPSCREW	4
22	QUB04414	CAPSCREW	2


Grabber Body Breakdown



GRABBER COMPLETE BREAKDOWN

Item	Item Tag	Description	Quantity
1	HYC00977	CYLINDER	1
2	186497	PIN, Grabber Cylinder	1
3	QUG00300	FITTING, Grease	1
4	186496	LOCK, Pin	1
5	QUB01990	CAPSCREW	2
6	QUR01261	WASHER, Lock	2
7	QUR01695	WASHER	2
8	186512	SHIM, Bracket R.H.	2
9	193050	BRACKET, Finger R.H.	1
10	186515	CAPSCREW, Bracket R.H.	1
11	QUE02476	NUT	1
12	186514	CAPSCREW	1
13	QUE02420	NUT	2
14	QUG00200	FITTING, Grease	3
15	193048	BRACKET, Finger L.H.	1
16	186513	CAPSCREW, Bracket L.H.	1
17	QUB05803	CAPSCREW	2
18	QUE08000	NUT	4
19	186511	SHIM, Bracket L.H.	2
20	223634	ASSY., Transition Arm	1
21	193039	FINGER	2
22	193041	CLAMP, Rubber	2
23	186499	SUPPORT, Rubber Strap	4
24	QUV00750	CAPSCREW, Flat Head	4
25	QUV02450	CAPSCREW, Flat Head	4
26	186500	BRACKET, Rubber strap	1
27	QUB06250	CAPSCREW	2
28	QUR01700	WASHER	8
29	QUE01101	NUT	8
30	QUB04414	CAPSCREW	2
31	ETR00300	TAPE, Reflective	2

Grabber Complete Breakdown




GRABBER CYLINDER HYD BREAKDOWN

Item	Item Tag	Description	Quantity
1	HYC00977	CYLINDER	1
2	HYF07400	ADAPTOR, 90°	1
3	HYF04805	ADAPTOR, Straight	1
4	224747	HOSE	1
5	HYS00300	SUPPORT, Hose	1
6	224746	HOSE	1
7	HYS00150	SUPPORT, Tube	4
8	223644	TUBE	1
9	223645	TUBE	1
10	HYF07300	ADAPTOR, 90°	4


GRAVITY LATCH BREAKDOWN

Item	Item Tag	Description	Quantity
1	223694	COVER	1
2	HYC00055	CYLINDER	1
3	QUE04250	NUT	2
4	QUB06200	CAPSCREW	4
5	QUR01272	WASHER, Lock	4
6	QUR01902	WASHER	4
7	223702	HOSE	1
8	HYF07300	ADAPTOR, 90°	1
9	HYF06490	ADAPTOR, Straight	1
10	QUB05081	CAPSCREW	1
11	QUR02130	WASHER	1
12	QUE02416	NUT	1
13	223688	LATCH	1
14	HYV03872	SPRING	1
15	QUR02005	WASHER	1
16	QUB03725	CAPSCREW	1
17	QUE01302	NUT	1

Grabber Cylinder HYD Breakdown




Gravity Latch Breakdown



LIFT ARM BREAKDOWN

Item	Item Tag	Description	Quantity
1	223632	BUSHING	2
2	186522	SPACER	1
3	186457	STOPPER	2
4	223553	LIFT ARM, Assy.	1
5	QUV02425	CAPSCREW, Flat Head	4
6	QUR01700	WASHER	4
7	QUE01101	NUT	4
8	223641	PIN, Arm Pivot	1
9	QUG00200	FITTING, Grease	1
10	223660	PIN, Arm Lift Cylinder	1
11	QUE01302	NUT	1
12	QUB04414	CAPSCREW	2
13	QUB06200	CAPSCREW	1
14	QUR01912	WASHER	2
15	QUR01902	WASHER	2
16	QUR01300	WASHER, Lock	2


Lift Arm Breakdown



LIFT CYLINDER BREAKDOWN


Item	Item Tag	Description	Quantity
1	HYC00622	CYLINDER	1
2	HYF04875	ADAPTOR, Straight	2
3	HYF07840	ADAPTOR, 45°	2
4	223682	HOSE	2
5	HYS00621	SUPPORT, Hose	2
6	ELA01300	SUPPORT, Hose	5

Lift Cylinder Breakdown




SLIDE BASE BREAKDOWN

Item	Item Tag	Description	Quantity
1	223639	SLIDE HOUSING, Frame Assy. (Includes Item 3)	1
2	CIB01190	CUSHION, Slide Cylinder Support	1
3	186487	CYLINDER BRACKET, Assy. (Included in Item 1)	1
4	223651	PIN, Arm Slide Cylinder	1
5	QUB06200	CAPSCREW	2
6	QUR01902	WASHER	40
7	QUE01302	NUT	20
8	HYS00621	SUPPORT, Hose	1
9	QUB05605	CAPSCREW	8
10	QUR00910	ROLLER	1
11	186450	PIN, Roller	1
12	QUB03501	CAPSCREW	4
13	QUE01303	NUT	4
14	QUB03730	CAPSCREW	10
	223638	SLIDE HOUSING, Assy. (Included Items 1-3, 5-7, 10, and 11)	



TRUCK HYD CONNECTION BREAKDOWN

Item	Item Tag	Description	Quantity
1	211378	HOSE	2
2	HYF01800	ADAPTOR, Straight	2
3	HYF10210	COUPLER	1
4	HYF10211	COUPLER	1




VALVE ASSEMBLY BREAKDOWN

Item	Item Tag	Description	Quantity
1	223539	COVER, Valve	1
2	HYV08420	VALVE, Assembly	1
3	HYF04875	ADAPTOR, Straight	6
4	HYF07950	ADAPTOR, 90°	2
5	HYF04900	ADAPTOR, Straight	2
6	HYF05162	ADATOR, 90°	1
7	223695	BRACKET, Valve	2
8	HYF07450	ADAPTOR, 90°	1
9	HYF11350	PLUG	1
10	HYF08000	ADAPTOR, 90°	3
11	HYF06116	ADAPTOR, Tee	1
12	HYF06116	ADAPTOR, Straight	1
13	HYF10193	COUPLING, Test	1
14	QUR01800	WASHER	12
15	QUR01271	WASHER, Lock	12
16	QUB02701	CAPSCREW	4
17	QUB02803	CAPSCREW	8

VALVE ASSEMBLY CONNECTION BREAKDOWN

Item	Item Tag	Description	Quantity
1	224748	HOSE	1
2	224749	HOSE	1
3	HYS00621	HOSE, Support	1
4	HYF05690	ADAPTOR, Tee	1
5	HYF06490	ADAPTOR, Straight	2
6	HYF07950	ADAPTOR, 90°	1
7	224751	HOSE	1
8	218841	HOSE	1
9	HYV06167	VALVE, Pressure Reducing	1
10	HYF05158	ADAPTOR, 90°	1
11	QUB02402	CAPSCREW	2
12	QUR01700	WASHER	8
13	HYF04800	ADAPTOR, Straight	2
14	HYF04801	ADAPTOR, Straight	1
15	HYF07400	ADAPTOR, 90°	2
16	QUB02411	CAPSCREW	2
17	223703	HOSE	1
18	HYV00888	VALVE, Solenoid	1
19	224752	HOSE	1
20	223697	BRACKET, Valve	1
21	QUE01101	NUT	4
22	QUB02803	CAPSCREW	4
23	QUR01271	WASHER, Lock	4
24	QUR01800	WASHER	4
25	224745	SHIM	2

Valve Assembly Breakdown



Valve Assembly Connection Breakdown

